

TOMMY TUTONE BAND

PRODUCTION MANAGER - JIMMY JAMES 813.598.4990

| INPUT | ALT. | INSTRUMENT | MIC/DI | STAND/NOTES ETC | STAGE POSITION | STAGE BOX |
|-------|------|------------------------|------------------|------------------|----------------|-----------|
| 1 | | KICK IN | D112 | | DRUM RISER | |
| 2 | | KICK OUT | E602 | SHORT BOOM | DRUM RISER | |
| 3 | | SNARE TOP | SM57 | SHORT BOOM | DRUM RISER | |
| 4 | | HI HATS | SM81 | SHORT BOOM | DRUM RISER | |
| 5 | | RACK TOM | E604 | CLAMP | DRUM RISER | |
| 6 | | RACK TOM | E604 | CLAMP | DRUM RISER | |
| 7 | | FLOOR TOM | E604 | CLAMP | DRUM RISER | |
| 8 | | OVERHEAD - LEFT | KSM 32 | TALL BOOM TRIPOD | DRUM RISER | |
| 9 | | OVERHEAD - RIGHT | KSM 32 | TALL BOOM TRIPOD | DRUM RISER | |
| 10 | | BASS DI | RADIAL ACTIVE DI | | STAGE LEFT | |
| 11 | | GTR 1 - MARSHALL LEAD | E609 | ZBAR | STAGE RIGHT | |
| 12 | | GTR 2 - VOX RYTHM | E609 | ZBAR | CENTER STAGE | |
| 13 | | GTR 2 - MARSHALL COMBO | E609 | ZBAR | CENTER STAGE | |
| 14 | | DRUM VOX 1 | SM58/E835 | BOOM TRIPOD | DRUM RISER | |
| 15 | | BASS VOX 2 | SM58/E835 | BOOM TRIPOD | STAGE LEFT | |
| 16 | | RHYTHM GTR VOX 3 | SM58E835 | BOOM TRIPOD | STAGE RIGHT | |
| 17 | | LEAD VOX 1 - CTR | SM58 | STRAIGHT STAND | CENTER STAGE | |